



## EMILFOGGER DEVICE INSTRUCTIONS GUIDE



## Attention!

Instructions and warnings for safe and effective use.

Before using the device, carefully read the instructions for use and in particular the safety warnings, following them. Keep this manual for the entire life of the device for consultation purposes. In the case of the sale of the device to third parties, also hand over the entire documentation. If reading this instruction booklet makes some parts difficult to understand or if you have doubts, contact the company at the bottom of the page before using the product.

## WARNINGS ON USE

In order to create an effective vaporizing effect you need to set the air pressure of the compressor to 5 bars. With this air pressure, the nozzle will "call" about 110 l/min, for this reason it is necessary to use compressors that have an air intake capacity of at least 200 l/min, regardless of the capacity of the tank.

The EmilFogger is designed to work indoors and with low volumes (up to 150 m3). The maximum height of the rooms must not exceed 4 meters and the maximum surface must not exceed 50 square meters in order to ensure a correct and uniform propagation of the product.

In case you want to work in environments with larger surfaces and volumes (respecting the maximum height of 4 meters) you can use multiple EmilFoggers in combination, placing them in opposite corners.

The EmilFogger itself does not guarantee the sanitization of the environments. It is a DEVICE SUITABLE to vaporize chlorine-based disinfectant solutions that, when used at the right concentrations, can ensure the sanitization of environments.

## SAFETY WARNINGS

- ! Do not use in the presence of people.
- ! Avoid entering treated environments for at least 3 hours after the end of treatment to allow free fall of particles within the environment ensuring the effectiveness of thetreatment.
- ! Depending on the product used for treatment it is recommended to let fresch air into the treated environments for at least 10 minutes after 3 hours after the end of treatment.
- ! Keep out of children's reach.

